

DSView® 3 Management Software Plug-in for Dell Remote Console Switch (1082DS/2162DS/4322DS)

Using Online Help

Use this guide to locate information about the DSView 3 management software plug-in for Dell Remote Console Switch (1082DS/2162DS/4322DS) by:

- Clicking the *Contents* tab to browse the contents
- Clicking the *Search* tab to perform a full text search
- Clicking the *Favorites* tab to bookmark topics for future reference

Check out the [Avocent web site](#) on a regular basis for the latest firmware updates, documentation revisions and technical information.

For Customer Support

Call: 1-888-793-8763


00353-61-715-292 (International)

Visit: <http://www.avocent.com/support>

Download: <http://www.avocent.com>

Avocent, the Avocent logo, The Power of Being There and DSView are registered trademarks of Avocent Corporation or its affiliates in the U.S. and other countries. All other marks are the property of their respective owners.

© 2010 Avocent Corporation. 59E-1038-501A



DSView[®] 3 Management Software Plug-in for Dell Remote Console Switch (1082DS/2162DS/4322DS)

The Avocent[®] DSView 3 management software plug-in allows you to access and control Dell 1082DS, 2162DS and 4322DS switches and attached target devices from the DSView 3 management software. You can launch a KVM session to a target device from a single point of access.

The information provided in this technical bulletin is supplemental to the DSView 3 help and the Dell™ Remote Console Switch User's Guide.

NOTE: The term "Dell switch" in this document refers to Dell 1082DS, 2162DS, or 4322DS switches.

System Requirements

DSView 3 management software requirements

- DSView 3 software version 3.7.1 or later
- Dell DSView 3 plug-in

Plug-in Installation

For information on how to install a plug-in, see the DSView 3 help (keyword: plug-ins).

Operations

To begin managing a Dell switch with the DSView 3 software, first add or discover the switch to the DSView 3 software. See the DSView 3 help (keywords: adding units) for more information. The added Dell switches and attached target devices are available in the Units View windows in the DSView 3 software. For more information about navigation and actions that can be performed from Units View windows, see the DSView 3 help (keywords: units view windows).

DSView 3 software administrators may assign unit access rights for each Dell switch. Unit access rights allow administrators to specify which users or user groups may perform certain actions for a unit type. See the DSView 3 help (keywords: unit access rights) for more information.